

## Errata

July, 1969 (Vol. 6, No. 2)

**Page 80:**

In the 11th line of the right-hand column, the expression "axial load in the bracing" should read "axial load in the column."

**Page 81:**

In Equation 6, the numerical factors "11/22" should read " $\frac{1}{2} \cdot \frac{1}{2}$ ".